

1 Ventilation Checklist 1—Forced Air Systems SENTENCE 9.32.3.4(6)

Use this Checklist where **forced air heating system ducts intake and distribute** ventilation air.

Civic Address _____		Permit No. _____	
Climate Zone: ____	Number of Bedrooms	<input type="text"/>	(A) A bedroom is a room with an openable window (minimum dimensions apply), a closet and a closing interior door.
Total Floor area of conditioned space		<input type="text"/> ft ²	(B)
Total Interior Volume of Dwelling		<input type="text"/> ft ³	Total volume includes all heated interior spaces
.5 ACH (air changes/hr) = Volume x 0.5 ÷ 60 =		<input type="text"/> cfm	(C) Exhaust appliances exceeding .5 ACH may require make-up air.

1. Principal Ventilation System Exhaust Fan Minimum Air-flow Rate

Use the bedroom count from Box (A) and Total square footage from Box (B) above and Table 9.32.3.5. to determine

Minimum Required Principal Exhaust System Capacity cfm (D)

2. Principal System Fan Choice

a) Exhaust Fan continuous running Make _____ Model _____ Sone Rating _____

Location: _____ **Capacity at 0.2 ESP** cfm (E) Must be ≥ than Box (D)
If CEV, capacity @0.4ESP

3. Fan Duct Size and Equivalent Length

Use actual fan cfm in Box(E) above and Table 9.32.3.8 (3) [See note at bottom of page for larger fan duct sizing].

a) Length of duct _____ft + Exterior hood 30ft + number of 90° elbows _____ X 10 ft = _____ **Equivalent Length**

Maximum Equivalent Length allowed in Table 9.32.3.8(3) = _____

b) Fan Duct size: _____ inches Ø Duct type: ___ Rigid ___ Flex

4. Required Kitchen and Bathroom Exhaust Fans: Re-list below if Principal Exhaust Fan meets all or part of Kitchen/Bathroom spot Exhaust requirements.

ROOM	REQUIRED EXHAUST RATE Table 9.32.3.6	EXHAUST EQUIPMENT						Ex.Fan/CEV Principal System CFM
		Spot Exhaust Kitchen & Bath WALL/CEILING FANS					Principal System CFM	
		Fan Make & Model	CFM @ 0.2 ESP Manf. Rated	*Duct Sizing per Table 9.32.3.8.(3)		Max. Equiv. Length per table		
		rigid	flex					

* For fan capacities **exceeding** 175cfm in Table 9.32.3.8(3), follow manufacturer's installation instructions or use good engineering practice to size duct.
See *Ventilation Guidelines* Appendix page 16-A

TOTAL (must = Box E)	
----------------------------	--

